



Carbon Footbar Installation

Please read all instructions thoroughly. If you have ANY questions prior to starting your installation, please call the factory at 866-386-1881 to discuss before you start working.

1. Determining the position of the foot bar tacks will depend on where it is being installed in the boat (bow, stern, center). Generally, our foot bars are installed approximately 15" from the seat and 5" from the floor of the boat but that can be adjusted to accommodate your own leg length.
2. At our factory, we use large adjustable 10" C clamps to hold everything in place. Be sure to lightly clamp everything in place, tightening the clamps too much could result in a dent on the exterior of the boat. Before gluing, clamp the foot bar tracks in place with the bar in place to ensure everything is lining up and working properly. If not, adjust the rails as needed and mark the new position with a pencil. Using 80 grit sandpaper, lightly scuff up the interior of the boat where the tracks will go. This gives the adhesive a better bond.
3. The adhesive provided in the kit is a fast curing (5 minutes) 2-part adhesive. On a piece of scrap cardboard or wood, dispense the adhesive and mix the 2 parts together well. Spread a generous amount of adhesive on the back side of both tracks and clamp them into position with the foot bar in place to again ensure, everything is lining up properly.
4. Once clamped, clean up any excess adhesive that squeezes out around the tracks. Let cure for 10-15 minutes before unclamping.



Swift Canoe & Kayak

2394 Highway 11 North, Gravenhurst, Ontario P1P 1R1 705.687.3710

1.800.661.1429 www.swiftcanoe.com