



Tumpline Installation

(Carbon Kevlar Trim)

Please read all instructions thoroughly. If you have ANY questions prior to starting your installation, please call the factory at 866-386-1881 to discuss before you start working.

1. Measure and mark with a pencil, 2" in front of the center yoke of both sides of the canoe. Using the included pad eye brackets as a template, mark the two screw holes in the bracket at the 2" mark just under your trim.
2. Using a small 1/16" drill bit, drill pilot holes for the 4 screws.
BEFORE DRILLING, make sure the angle that you are drilling into the trim is in an upward angle towards the outer lip of the trim. You must ensure this to avoid drilling through your trim or the side of the canoe hull.
3. Once all your holes are drilled, prepare some fast-curing epoxy resin (not included in kit). Dip the screw into the resin and screw the brackets in place. The epoxy just helps to provide more security to hold the screws in place. Allow the epoxy to cure for the recommended time provided on the packaging before using the tumpline.

If you do not feel comfortable drilling into your trim, please drop your canoe off at our Service Centre in South River and we will be happy to have our factory technicians do the installation for you



Swift Canoe & Kayak

2394 Highway 11 North, Gravenhurst, Ontario P1P 1R1 705.687.3710

1.800.661.1429 www.swiftcanoe.com